

**Maintenance Recommendations**

**for Grilles, Registers, Diffusers and related accessories**

1. **Always turn equipment/ system off when performing maintenance or cleaning Grilles / Registers / Diffusers, etc.**
2. **Cleaning:**
  - a. When fitted, remove grille / register from auxiliary frame.
  - b. Unit may be cleaned by rinsing in warm soapy water, dry thoroughly with soft cloth.
  - c. When a damper is affixed to the grille, carry out the same cleaning procedure as above. When dry, the moving parts may be lightly lubricated with a clear lubricant (Vaseline) if necessary.
  - d. Units that cannot be removed from their installed location may be washed on site using warm soapy water and dried with a soft cloth.
  - e. Stainless steel grilles and diffusers can be cleaned with a harsher cleanser. Rinse stainless steel grilles and diffusers thoroughly after cleaning, dry thoroughly and lubricate if necessary.
3. **Operation:**
  - a. Units with integral dampers may be operated by employing a screwdriver (straight tip) to operate the screw adjustment. This should only be carried out by System Balancing Technicians.
4. **Maintenance:**
  - a. Other than cleaning and adjusting as noted above, no other maintenance is normally required.

<b>PROJECT:</b>		<b>PRICE<sup>®</sup></b>	
<b>ENGINEER:</b>		<i>DS</i>	<b>MAINTENANCE RECOMMENDATIONS</b>
<b>CUSTOMER:</b>		222850	
<b>SUBMITTAL DATE:</b>	<b>SPEC. SYMBOL:</b>	APRIL 2000	